

SQUARE SHOWER BATH PANEL ASSEMBLY INSTRUCTIONS

1. Place cam plates in the back of panels A,B,C and D in the pre-drilled holes provided.
2. Screw into place the cam dowells as shown.
3. Push and glue in place the wooden dowells as shown.
4. Glue all edges to be butted together, being carefull not to get any adhesive on the decorative surfaces, push panels together one at a time and tighten in position by turning the dowell plates.
(any excess adhesive must be removed immediatly with a damp cloth)
5. The fillet post can be glued in position after fitting to the bath if required.
6. Instruction shows L/H panel for R/H version follow instrctions in reverse.

