

Construct frame from 32 x 32 PAR softwood to form an aperture 15mm narrower than dimension 'X' and 200mm high.

Existing partition wall studding

Backplate

Use Backplate to position and drill 2 x 10mm diameter holes, countersunk to 16mm diameter

Fix Backplate to rear of frame with 2 No. M8 x 50 countersunk bolts, nuts and washers (not supplied)

Note: Size and style of plate may vary depending on model chosen.

Fit Lever/spout assembly to backplate with 4 No. M6 x 40 countersunk mirror screws (supplied).

