



1. CONNECT TRAP TO BATH WASTE ENSURING FIBRE WASHER IS IN PLACE
2. CUT OUTLET BEND TO REQUIRED LENGTH (FOR WALL OR FLOOR OUTLET)
3. SLIDE FREE NUT ONTO OUTLET BEND. FLANGED SIDE FIRST
4. PLACE FIBRE WASHER AND RUBBER SEAL ONTO OUTLET PIPE.
5. TIGHTEN FREE NUT ONTO TRAP.
6. FIT FLANGE OVER SHORT END OF OUTLET BEND.
7. ATTACH MULTI-FIT CONNECTOR TO SHORT END OF OUTLET BEND
8. CHECK FOR LEAKS
9. PUSH FLANGE AGAINST FLOOR OR WALL